




Fig.11

Fig.12 Serviceable Condition

Backer webbing covers the fall indicator

WARNING.




Fig.13 Fall Indicator



Factory Attached E/A Warning and Instruction Labels

Primary Labels Standard E/A



English/Spanish E/A w/Rope Grab



ANSI Z359.13 Label



Fig.14

No.6179 E/A Cover

Accessory cover attaches with hook and loop and is removable for inspection. Use in work areas where the E/A is exposed to abrasive surfaces. Fits all standard and Ultra-Lite™ E/As.



Pg.12