

Annual and Daily Inspections:

Inspect all harness components prior to each use and inspect annually by a competent person. A written plan for service, maintenance, removal from service and user training should be maintained for each harness. The following inspection points may be used as a guideline to inspect for normal wear, tear and abuse. Record inspections on the "Inspection Label".

Remove equipment from service if any of the following conditions are present:

⊗= Inspection points **ACTION REQUIRED:** ☒=Remove ☑=SAS Factory Repair
ANSI-CSA and OSHA require that a harness subjected to a free fall must be removed from service immediately and disposed of in a way that prevents further use. ☒

- 1 Has not been inspected annually. ☒
Check inspection label for data entry.
- 2 Warning labels missing or not legible. ☒
- 3 Fall Indicator label/s are missing or warning is visible. ☒ Figs.5,6
- 4 Webbing cut, abraded, damaged by heat or chemicals. ☒
- 5 Webbing stitches cut or loose. ☒ Figs.2,3
- 6 Chest strap adjuster pad is missing or webbing slots are broken. ☒ Fig.3
- 7 Chest/Leg strap webbing end terminations are missing or stitching is damaged. ☒☑ Fig.3
- 8 Webbing keepers missing or damaged. ☒☒ May be replaced with SAS supplied elastic webbing keepers.
- 9 D-ring is deformed, cut, or evidence of pitting or extreme rusting. ☒
- 10 D-Pad is cut, torn, or webbing slots are broken. ☒ Fig.4
- 11 Buckles are missing, cut, deformed or evidence of pitting or rusting. Tongue buckle grommets missing. Quick connect buckle won't lock. ☒ Fig.3

Storage/Maintenance

Hang harnesses in dry area. Never store wet. Clean only with mild detergent, soft bristle brush or compressed air. DO NOT use bleach or corrosive cleaning materials.

DO NOT expose webbing to:

- Open flame
- High heat
- Sharp edges
- Electrical hazards
- Cutting tools or grinders
- Acids, chemicals, solvents or petroleum

WARNING!
Storing wet will cause mildew, resulting in damage to webbing and stitching.



Fig.2



Buckle Locking Test 11
Lock buckle and pull on each side of the chest strap. The buckle must remain locked to pass.



Fig.4

Tongue Buckle Grommets
If a grommet is missing DO NOT use the buckle in that position. 11



Fig.6

Fall Indicator deployed. 3
Warning is visible.



Product I.D.(PID) and Inspection Labels

<p>Primary Label Date of mfg.</p> <p>Model No. Specified Here</p>	<p>Instruction Label English</p> <p>USER SHALL COMPLY WITH SAFETY STANDARDS WHEN USING THIS EQUIPMENT!</p> <p>Harness Stretch (x3): 12"(303mm) Max Free Fall (ft.) (6): 2 Anchorage Point: 5,000lb(225kg) or 2x fall protection load when safety standards allow. Hardware Meets: ANSI/CSA</p> <p>WARNING: Read instruction manual. Inspect equipment and perform function tests before each use. Remove defective equipment from service. FALL INDICATORS: If warning is visible remove from service. Maintenance: Keep away from open flame. Do not store wet. Size Adjustment: Position D-Ring no lower than 12"(303mm) from top of shoulder, adjust leg, shoulder and chest straps for a snug fit. WARNING: Improperly adjusted harness may result in serious injury or death if a fall occurs. Length of Fall: Consult manual to calculate free fall length. RESCUE: Prolonged suspension may result in death. Rescue immediately!</p> <p>Item Label C/EN/English OSCR 06-2019 Tamaño: 142 (36) mm</p>	<p>Instruction Label Spanish</p> <p>¡LOS USUARIOS DEBERÁN ACATAR LAS NORMAS DE SEGURIDAD AL UTILIZAR ESTE EQUIPO!</p> <p>Estricción del arnés: (x3)=12"(303mm) Distancia máxima de caída libre: 2 pies (1.8m) Punto de anclaje: 5 000 lbs (225kg) o cuando las normas de seguridad lo permitan, 2 veces la carga a proteger en la caída. Equipos: cumplen con ANSI / CSA.</p> <p>ADVERTENCIA: Lea el manual de instrucciones. Antes de cada uso, inspeccione el equipo y realice pruebas de funcionamiento. Retire de servicio al equipo está defectuoso. INDICADORES DE CAÍDAS: Si la etiqueta de advertencia es visible, retire el equipo de servicio. Mantenimiento: Manténgalo alejado de flamas abiertas. No guardarlo mojado. Ajuste de tamaño: Posicione el Anillo-D no más abajo de 12"(303mm) desde la parte superior del hombro, ajuste las correas de las piernas, hombros y pecho para un ajuste cómodo. ADVERTENCIA: Arneses mal ajustados pueden resultar en heridas, lesiones o muerte en caso de caída. Distancia de caída: consulte el manual para calcular la distancia de caída libre. RESCATE: La suspensión prolongada puede ocasionar la muerte. (Rescatar inmediatamente)</p> <p>Item Label C/2E/Spanish OSCR 06-2019 Tamaño: 142 (36) mm</p>	<p>Inspection Label 1</p> <p>Serial No. []</p> <p>Date of Use: []</p> <p>Inspection</p> <table border="1"> <thead> <tr> <th>MM</th> <th>YY</th> <th>By</th> <th>Pass</th> </tr> </thead> <tbody> <tr><td> </td><td> </td><td> </td><td> </td></tr> <tr><td> </td><td> </td><td> </td><td> </td></tr> <tr><td> </td><td> </td><td> </td><td> </td></tr> <tr><td> </td><td> </td><td> </td><td> </td></tr> <tr><td> </td><td> </td><td> </td><td> </td></tr> <tr><td> </td><td> </td><td> </td><td> </td></tr> <tr><td> </td><td> </td><td> </td><td> </td></tr> <tr><td> </td><td> </td><td> </td><td> </td></tr> <tr><td> </td><td> </td><td> </td><td> </td></tr> <tr><td> </td><td> </td><td> </td><td> </td></tr> </tbody> </table> <p>WARNING TO USER You are required to read and use the instruction/Specificativa manual supplied at the time this device was shipped. Improper use and installation can result in serious injury or death.</p> <p>MADE IN CANADA / VOUS DEVEZ LIRE ET UTILISER LE MANUEL D'INSTRUCTIONS FOURNI AVEC LE LIENVOU VOUS DEVEZ LIRE LE MANUEL D'UTILISATION EN FRANÇAIS. L'INSTALLATION INAPPROPRIÉE PEUT CAUSER DE SÉRIEUSES LÉSIONES OU LA MORT.</p> <p>ADVERTENCIA: Arneses mal ajustados pueden resultar en heridas, lesiones o muerte en caso de caída. Distancia de caída: consulte el manual para calcular la distancia de caída libre. RESCATE: La suspensión prolongada puede ocasionar la muerte. (Rescatar inmediatamente)</p>	MM	YY	By	Pass																																								
MM	YY	By	Pass																																												