SUPER ANCHOR SAFETY®

CRA Commercial Roof Anchors Instruction/Specification Manual 01-2021

Material Specifications

Imported: Q235 Steel, 304sst. Domestic: A-36, 304sst, 316sst. Finish: ASTM 123 Hot dip galvanized. Loop Tops: No.1090=Q235 cast steel.

No.1090-S=316 cast sst. Low Temperature: -30°F to +130°F Foam Filling: Polyurethane References: SAS= Super Anchor Safety

(X) = Inspection Points "Qualified" and "Competent Person"

See OSHA definitions.

Specified Use

Single Person Anchor: Max. user wt. 340lb including tools and equipment. Used as an anchorage connector designed to support a suspended component/tie-back line or an active fall protection system with a maximum free fall exposure of 6ft(1.8m). Fall arrest, work positioning and fall restraint. PPE Equipment: Users are required to wear a full body harness (FBH), a personal energy absorber

and other fall protection components that comply with current OSHA/ANSI/CSA standards. Horizontal Lifelines (HLL): End anchors as shown on pg.4.

Window Washing: Fall Arrest and boatswain suspension anchors.

Alternate Installation: May be installed vertical or inverted as specified by the project engineer.

Structural Support

The anchor attachment point must be capable of supporting 5,000lb or 2x the intended fall protection load per OSHA 1910.140(13). See Window Washing section below.

Anchor Spacing

Anchor structural attachment locations are specified by the project architect, engineer. or safety consultant. Single person and HLL's anchors are spaced 20-30ft o.c. Window washing anchors are spaced 12ft o.c. or less (Fig.5,6).

Fastener Options: See Page 3.

Screws: Use only SAS factory supplied No.2022 hex head. HeadLOK™ or WS screws. Max. Riser Ht. Single person anchor with a max. riser height of 18". DO NOT use screws for window washing or HLL end anchors. Bolts: Risers over 18" must be bolted, field welded, or concrete embedded. Alternate fastener types may be used when specified by a gualified or competent person*. *See OSHA definition.

Wood Substrates: Min.3/4" plywood or 1-1/2" T/G decking requires 40ea. No.2022 #14 hex head screws, WS Screws or HeadLOK gimlet point wood screws (Figs.13,22,25,26).

Type B Metal Decking: Min. 22 gauge or thicker requires 36ea. No.2022 screws through the top flange only (Figs.4,7). Insulation Panels: Use SAS supplied HeadLOK SD tip screws (Fig.12).

Bolts: Grade 8, grade 5, 18-8 grade stainless steel and A307 threaded Rod. Use same grade lock nuts.

Window Washing Anchors

Bolt attached (Figs. 7, 8), field welded (Figs. 10, 11) or concrete embedded (Fig. 9). Two anchors are required for each drop point designation: 1 suspension rope anchor use for the workers boatswain chair and one fall arrest anchor. Anchors have spacing requirements (Figs.5,6). Consult SAS Window Washing manual for additional information.

ANSI/IWCA.1-14.1 applicable standards:

- 1) Analysis of the anchors structural supporting member shall be performed by a registered professional engineer*. 9.1.7
- 2) Anchors used for fall arrest shall be independent from the anchorage used for the suspension system, 13.3.3
- Fall arrest lifeline max. angle 15° from perpendicular. 5.7.17(d) 3)
- Workers may not reach more than 6ft left or right from the drop 4) point. 5.7.10
- 5) Anchors closer than 6ft from the roof edge, parapet wall or drop point. Max spacing between anchors is 12ft. Appendix C
- Anchors inspected annually by a "qualified" person, 9.1.9 6)
- Anchors recertified at least every 10 yrs. 9.1.9 by a registered 7) professional engineer. 9.1.10 *Project architect/engineer.

Consult SAS plan service for HLL's, PPE single anchor and window washing system design. 3rd party structural engineering available upon request.



*Intertek lab report 8-2020. 3rd party engineering: DH Glabe & Assoc.

Strength Rating

Ultimate Strength: Min. 5,000lb(22.5kN) in any direction the load is applied to a loop top. No.1090 loop top: 10,000lb min. tensile strength.

Proof Loading: Max. on site 2,500lb(11.3kN). DO NOT proof load screw attached anchors. 4-1 Design Load: 1.250lb(567kg).

Fig.6

Fall Arrest

Anchor

15° Max.

Drop Point

edge of roof

or parapet

15° Max.

Lifeline

Perpendicular +

Line

Center

suspension

rope over

window

Drop Point



WARNING TO USER!

Super Anchor Safety 17731 - 147th St. SE, Monroe, WA 98272 USA (425) 488-8868 www.superanchor.com

©SCN 2021 [MIT]

2ft Max.→

Use a min. of 4 each 1/2"diam. grade 8, grade 5, 18-8sst or A307 threaded rod with the same grade lock nuts. See Figs.7, 8, 21, 24. Backer plates are required when the supporting structural member or substrate does not meet the strength requirement for the intended fall protection load (e.g., concrete slabs that are less than 4" thick).

Type-B Metal Decking: Note that anchor bolt or screw attached to metal decking may flex when proof loaded.

Structural Steel and Wood Beams w/ Backer Plate

Use long bolts or A307 rod as close as possible to the beam edges (Figs.8,21). If necessary, drilling of plate bolt holes may be performed by a competent person only with *SAS* authorization. Order custom size base and backer (B/B) plates with bolt hole locations to fit structural members as specified by the project architect/ engineer.

Concrete Substrates

Wedge Type: 1/2" or greater diameter to be specified by the project architect/engineer and installed per bolt mfg. specifications. Flat washers are required. See Fig.9 and **Table 2** for bolt specifications.

Epoxy Type: Must be specified by the project architect/engineer to meet the intended fall protection load. **Poured-in-Place:** 1/2"diam. J-bolts or equivalent specified by the architect/engineer.

Concrete PSI: 2500lb min. concrete must be sufficiently cured to support the fall protection load prior to use.

Field Welded Anchors

Base plates may be welded to a structural steel member of the same or greater thickness (Figs.10,11) or as specified by the project engineer. Field welding is required to be performed by a certified welder using E70XX electrode or equal with a min. weld depth of 1/4". Field welding must be inspected by a "qualified" person. Anchors used for window washing must be proof loaded to 2,500lb prior to use for fall protection.

Fig.10 Field Weld Specifications



Fig.11 Field Welded Base Plate



Field Welding Apply 2 coats or more of a rust Preventative coating to all field welds.

ventative coating to all field welds.

Standard Corner Holes

Model Specifications

Standard CRA model designs shown in **Table 1.0** may be custom mfg. with specific riser heights, base plate dimensions and bolt hole diameters. Request custom mfg. **Vent Hole:** 3/8" threaded vent holes are required for welding (See Fig.17).

Base Plate Drain Hole: 1.0"diam. hole is required for Hot dip galvanizing process.

Table 1.0

Riser	Part Name	Part No.	Material Type	Loop Top		Riser Material		B /B		
Height				No.	Туре	0.D/wt.	Sch	Plate	Fastener	
△□8	CRA-8W	1035-W	▲ HDG	1090	Q235	3.0"		Wood su	Wood subs	
		1035-WS	304sst	1090-S	316sst	36lb	Type B i require 52-Hole Note: Pr	Type B me		
△□12	CRA-12W	1032-W	▲ HDG	1090	Q235	3.0" 40 0.203		require a r		
		1032-WS	304sst	1090-S	316sst			including t		
△□18	CRA-18W	1033-W	▲ HDG	1090	Q235	3.0" 46lb		literating		
		1033-WS	304sst	1090-S	316sst			Note: Pro		
∆ 24	CRA-24W	1042-W	▲ HDG	1090	Q235	3.0" 64lb	80 0.276	16"x16"x3/8"	Anchors at wood or m	
		1042-WS	304sst	1090-S	316sst			12-Hole		
∆30	CRA-30W	1025-W	HDG	1090	Q235	3.0" 79lb		12"x12"x5/8" s 4-8 Hole lo	SUDSTRATES	
		1025-WS	304sst	1090-S	316sst				loaded Re	
∆ 36	CRA-36W	1026-W	HDG	1090	Q235	3.0"	"	3.0"	12"x12"x3/4" te	tension an
		UNA-30W	1026-WS	304sst	1090-S	316sst	95lb		4-8 Hole	should ret

▲ Stock Part.

* Serial No. Tag stock models only. Custom models use PID label serial no.
□ #14 screw, bolt attached, concrete embedded or field welded.
△ Bolt attached, concrete embedded or field welded.

Insulated Panels w/Metal Decking

English Version Page 2

Bolt attach base plate on top of metal panel or insulation substrate w/backer plate.



Bolt Attached w/Backer Plate Structural Steel or Wood Beams





Table 2.0 Concrete Embedment

Model	Min. E	Page Dista		
Model	4 bolt	8 bolt	Dase Fidle	
CRA-W8	2.625	NI/A		
CRA-W	3.75	N/A		
CRA-W18	5.50 3.50		10"x10"	
CRA-W24	6.875	4.50	16"x16"	
CRA-W30		5.50		
CRA-W36		6.50]	

Reference: DHG report July 18-2018 pg.5. Hilti KB-TZ Expansion anchors or =.



B/B Plate Specifications

B/B plates have the same bolt hole size and locations. Standard backer plate models (Figs.14,15,16) are identical to the corresponding CRA anchor models. All anchor base plates may be field welded or used for concrete substrates. Backer plates may be supplied raw uncoated or hot dip galvanized. Custom size B/B plates are available on request. See Table 3.0.

Note: The drain hole is not counted as a bolt hole.

52-Hole 16"x16" B/B Plates

Specified for use with any 52-hole base plate anchors. Fabricated with 3/8" holes for use with #14 screws, WS-Screws and HeadLOK screws. 9/16"diam. holes shown in red are specified for 1/2"diam. bolts.



Hex Bolt

Grade 5, 8 or 18-8sst

1/8" Min.thread

penetration

Threaded

Rod

A307

Zinc

Plated

≓

Size to f

Fastener Specifications

Use only SAS factory supplied screws shown in product catalog. Use only certified grade bolts and lock nuts. Grade 5 bolts may be used if grade 8 lengths are not available. Bolts may be supplied by SAS on request. Consult bolt mfg. torque specifications for the bolt type.

Enlarging Bolt Holes

B/B bolt holes may be shop or field drilled for larger diameter bolts. Notify SAS for authorization. Apply rust preventive coating to bare metal. WARNING! DO NOT torch cut holes.

Loop Top Fixtures

No.1090/1090-S are compatible with snaphooks, carabiners, and SAS HLL end anchor components. Avoid incompatible connectors. Connector abrasion may wear the HDG coating causing red rust to appear. Remove rust and apply 2 coats of cold zinc spray.



16-Hole 16"x16" B/B Plates

Bolt attached B/B plates specified for use with CRA-24W or any 12- or 16-hole base plate anchors. 5/8" diam. holes are specified for 1/2"diam. bolts.

Fig.15



Table 3.0 Standard B/B Plate Specifications

Part No.	Name	Dimension	Bolt Holes		
1084	52-Hole	3/8"x16"x16"	40ea 3/8" 12ea 9/16"		
1085	16-Hole	5/8"x16"x16"	16ea 9/16"		
1409	8-Hole	5/8"x12"x12"			
1410 8-Hole		3/4"x12"x12"	8ea 5/8"		
1412	8-Hole	1-1/8"x12"x12"			

See Table 1.0 for applications.

8-Hole 12"x12" B/B Plates

Bolt attached B/B plates specified for use with 8-hole bolt attached base plate anchors. 5/8" holes are specified for a min. 1/2" diam. bolts.

Fig.16





Fig.20

· Connectors do not rotate freely.

Hilti

KB-TZ

or =

· Fittings or connectors not designed or specified for fall protection.

Loop Top **Side View**

Lock nuts/washers

both ends

←Window Washing/ HLL → **DO NOT Apply Load in This Direction**

Incompatible DO NOT attach two connectors to a loop top.





Wood Framing Details

When the primary sheathing is OSB or less than 3/4" plywood, a plywood backer installed under or over the top of the sheathing or a backer plate is required (Figs. 21-26). Attachment of the primary sheathing to the framing and the framing to which it is attached must be approved by the project engineer and be able to support the intended fall protection load.

Strongest Installation

- Attach center row fasteners to a top chord (Figs.22,23).
- Use a backer plate under the top chord (Fig.24).

The project architect/engineer may provide alternate framing/attachment specifications. Anchors attached with screws should not be on site proof loaded.

Inspections/Maintenance

SUPER ANCHOR SAFETY®

Prior to installation, inspect each anchor to confirm they are free from defects or damage caused by shipping or handling. Prior to use for fall protection, the project specific anchor installations must be inspected and certified by a qualified or competent person. Documented annual anchor inspections should be performed by the building owner's maintenance personnel. The inspection points in this manual are recommendations only and intended to be used as a guideline for the building owner's fall protection maintenance plan. Warning! Anchors subjected to a free fall or other damage must be tagged to prevent further use until inspected by a qualified or competent person. Remove from service if anchors do not pass inspection or if structural damage to the supporting structure has occurred.

Contact SAS for anchor inspection report or visit www.superanchor.com

