SUPER ANCHOR SAFETY®

Adjustable Web Lanyard No.6014-72A


WARNING TO USER!

Fig.2

Fig.1

ENGLISH VERSION

Instruction/Specification Manual 2022



MM

SUPER ANCHOR SAFETY®

Maintenance and Inspection

Perform snaphook function tests and visual inspections prior to each use. Numbered (①) inspection points are intended as guidelines only.

Employers and equipment owners are required to draft their own inspection outline. **SAS** requires annual inspections of fall protection equipment to be performed by a competent person*, entering the date of the inspection on the lanyards inspection label.

Note: Depending on use, greater frequency of inspections may be required.

Remove equipment from service if any of the following conditions are present:

S = Inspection points. ⊠=Remove ⊠=Repair

Webbing/Stitching/Buckle

- Cut, abraded or evidence of exposure to flame. Image: Image of the second second
- 🛿 Wear pad worn thru. 🗵
- 3 Stitching is cut, abraded or loose.

Adjuster Buckle

- 🕢 Won't hold position. 🗵
- 9 PID labels missing.
- 6 Elastic keepers missing. ☑

Snaphook Tests Table 1

- Does not pass function test. Image: Does not pass function test.
- Does not pass visual inspection. Image: Image Advancement Advance

WARNING HAZARD EXPOSURE! DO NOT CONTACT LANYARD WITH:

- Sharp, abrasive edges or cutting tools.
- Electrical sources or power lines.
- Open flame, high heat or hot asphalt.
- Solvents, caulking, paint or stains.
- DO NOT use for animal tether.

Fig.8

Adjuster Buckle Inspection

Inspect outside and inside frame for cracks or extreme corrosion.






Fig.9 Inside Frame Inspect bar frame intersections



Snaphook Function Tests

Lock gates are designed to remain closed during use. Perform Table 1 function/visual tests before each use and annually.

Table 1 Remove from service if any test fails.

Fig.	Test Type	Function	Pass 🗹	Fail 🗵
4a	Gate-lock	Push against gate only	Won't open	Opens
4b	Gate-open	Push gate-lock and gate at the same time	Opens	Won't open
4c	Gate-close	Release gate and gate- lock at same time	Snaps shut	Won't close and lock
4c	Rivets	Loose or missing rivets	Rivets intact	Rivets missing

